

BF135A - BF150A Maintenance Schedule

REGULAR SERVICE PERIOD(3) Perform at every indicated month or operating hour interval, whichever comes first.			Each use	After use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.	Every 2 years or 400 hrs.
ITEM								
Engine oil	Check level	See Owner's Maintenance Information.	●					
	Change				●	●		
Engine oil filter	Replace						● (2)	
Gear case oil	Change				● (2)	● (2)		
ACG belt	Check-adjust						● (2)	
Throttle linkage	Check-adjust				● (2)	● (2)		
Idling speed	Check-adjust				● (2)	● (2)		
Valve clearance	Check-adjust						● (2)	
Spark plug (Standard plug)	Check-adjust/Replace	See Owner's Maintenance Information.				●		
Propeller and cotter pin	Check		●					
Anode metal (Outside engine)	Check	See Owner's Maintenance Information.	●					
Anode metal (Inside engine)	Check							● (2) (4)
Lubrication	Grease				● (1)	● (1)		
Water separator	Check		●					

NOTE:

- (1) Lubricate more frequently when used in salt water.
- (2) These items should be serviced by your servicing dealer.
- (3) For professional commercial use, log hours of operation to determine proper maintenance intervals.
- (4) When there is 1/3 or more consumption, please wxchage.

REGULAR SERVICE PERIOD(3) Perform at every indicated month or operating hour interval, whichever comes first.			Each use	After use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.	Every 2 years or 400 hrs.	
ITEM									
Fuel filter	Check					●			
(Low pressure side)	Replace							●	
Fuel filter (High pressure side)	Replace							● (2)	
Thermostat	Check						● (2)		
Fuel line	Check		●						
	Replace	Every 2 years (if necessary) (2)							
Battery and cable connection	Check level-tightness	See Owner's Maintenance Information.	●						
Bolts and nuts	Check-tightness				● (2)	● (2)			
Crankcase breather tube	Check						● (2)		
Cooling water passages	Clean	See Owner's Maintenance Information.		● (4)					
Water pump	Check						● (2)		
Emergency stop switch	Check		●						
Engine oil leak	Check		●						
Each operation part	Check		●						
Engine condition (5)	Check		●						
Power Trim/Tilt	Check					● (2)			
Spark plug	Check						●		
(Optional iridium plug)	Clean						● (2)		
	Replace							●	

NOTE:

(1) Lubricate more frequently when used in salt water.

(2) These items should be serviced by your servicing dealer.

(3) For professional commercial use, log hours of operation to determine proper maintenance intervals.

(4) When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.

(5) Upon starting, check for unusual engine sounds and cooling water flowing freely from the check hole.