

BF60A Maintenance Schedule

REGULAR SERVICE PERIOD(3) Perform at every indicated month or operating hour interval, whichever comes first.			Each use	After use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.	Every 2 years or 400 hrs.
ITEM								
Engine oil	Check level	See Owner's Maintenance Information.	●			●		
	Change				● (2)	● (2)		
Gear case oil	Change				● (2)	● (2)		
Engine oil filter	Replace						● (2)	
Timing belt	Check-adjust						● (2)	
Throttle linkage	Check-adjust				● (2)	● (2)		
Idling speed	Check-adjust				● (2)	● (2)		
Valve clearance	Check-adjust						● (2)	
Spark plug	Check-adjust-Replace	See Owner's Maintenance Information.				●		
Propeller and cotter pin	Check		●					
Anode (Outside engine)	Check	See Owner's Maintenance Information.	●					
Anode (Inside engine)	Check							● (2) (7)
Lubrication	Grease				● (1)	● (1)		
Fuel tank and tank filter	Clean						●	
Thermostat	Check						● (2)	
Fuel filter	Check		● (5)			●		
(Low pressure type)	Replace							●
Fuel filter	Check					● (2)		
(High pressure type)	Replace							● (2)
Fuel line	Check		●					
	Replace				Every 2 years (If necessary) (2)			
Battery and cable connection	Check level-tightness	See Owner's Maintenance Information.	●					
Bolts and nuts	Check-tightness				● (2)	● (2)		
Crankcase breather tube	Check						● (2)	
Cooling water passages	Clean	See Owner's Maintenance Information.		● (4)				
Water pump	Check						● (2)	
Emergency stop switch	Check		●					
Engine oil leak	Check		●					
Each operation part	Check		●					
Engine condition (6)	Check		●					
Power Trim/Tilt	Check					● (2)		

(1) Lubricate more frequently when used in salt water.

(2) These items should be serviced by your servicing dealer.

(3) For professional commercial use, log hours of operation to determine proper maintenance intervals.

(4) When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.

(5) Please check water accumulated before use.

(6) Check startability, engine sounds and cooling water check hole.

(7) Replace the anode metal when it has been reduced to approximately one third of its original size.